

50 SERIES OPERATING INSTRUCTIONS

Operating Instructions:

1. Insert connector onto test piece. Make sure a minimum of .260 of engagement is achieved. This will ensure proper seal life and gripping ability.



2. Cam the handle 90° from the charge port.



3. Test media can be introduced thru the 1/8" NPT charge port.



4. After your test is completed vent the system then remove the connector.

Adjustment:


1. If the RAMSEAL® connector is not sealing properly some adjustment may be needed.
2. The head and body are set using Loctite® from the factory. Uses a 7/8" wrench to break the Loctite® lose.
3. Clockwise to tighten.



4. Counterclockwise to loosen.



Replacement Parts and Assembly Diagram:



ITEM NO.	PART NO.	DESCRIPTION
1	5002-*	Handle
2	5003	Handle Pin
3	5001	Body
4	5004	Insert (Deadhead Version Available)
5	5014	Plug Seal
6	5008	Seal
7	5006-*	Collet
8	5005	Head

* Specify Model Number, and /or Tube I.D. and O.D.